

<u>DAY</u>	<u>JUNE</u>	<u>DESCRIPTION</u>
21	29	Drill 17-1/2" hole from 4231' - 4566'.
22	30	Drill and survey 17-1/2" hole from 4566' - 4764' POOH. Unlatch LMRP and L/D Riser, W.O.W.
<u>DAY</u>	<u>JULY</u>	<u>DESCRIPTION</u>
23	1	L/D Riser, W.O.W.
24	2	WOW. Run LMRP, position rig, WOW.
25	3	WOW.
26	4	WOW. Position rig, land LMRP, test BOP connectors.
27	5	Test BOP connectors, RIH and break circulation every 1000'. Wash + ream bridge from 4041' - 4122'. Wash 30' fill on bottom. Drill 17-1/2" hole from 4764' - 4913'.
28	6	Drill 17-1/2" hole from 4913' - 5175'.
29	7	Drill and survey 17-1/2" hole from 5175' - 5220'. POOH for new bit. RIH, 39' fill. Drill 17-1/2" hole from 5220' - 5342'.
30	8	Drill and circulate samples in 17-1/2" hole from 5342' - 5735'.
31	9	Drill 17-1/2" hole from 5735' - 5769'. Circulate and condition hole for logging. Drop multi-shot, and POOH. Rig up and run Schlumberger ISF-BHC-MSFL-GR-CAL log. Rig for cleanout trip.
32	10	RIH and circulate and condition hole. POOH for short trip. RIH, 17' fill. Displace hole w/10.5 ppg mud. POOH to run 13-3/8" casing.