

QUALITY CHECK OF SAMPLES RECEIVED IN THE LABORATORY

<u>Cylinder #:</u>	SS 1069	SS 982
<u>Opening Pressure:</u>	200 psig @ 67°F	280 psig @ 66°C
<u>Sample #:</u>	1	2

<u>cm³ Mercury Injected</u>	<u>Pressure, psig</u>	<u>cm³ Mercury Injected</u>	<u>Pressure, psig</u>
0	312	0	380
1	315	1	382
2	318	2	385
3	321	3	387
4	324	4	390
5	365	5	435
6	405	6	475
7	445	7	520
8	485	8	565
9	525	9	610
10	565	10	655
11	605		

Psat = 324 psig @ 67°F

Psat = 390 psig @ 66°F