

Drilling Day # 8 (12.7.82) cont.

Circulate 15 minutes, LOT 9.2 ppg maximum at 50 psi.

Drill from 1450ft. to 2017ft. pumping 25 bbls of high viscous mud every 2 joints.

Circulate and drill from 2017ft. to 2022ft.

Drilling Day # 9 (13.7.82)

Drill ahead from 2022ft. to 2067ft.

Circulate and POOH. Change Bit, new Bit # 6, run sequence # 7.

Work past bridge at 2018ft., wash to 2067ft.

Drill ahead to 2091ft.

Stuck pipe at 2091ft., work free.

Reaming down from 2070ft. to 2091ft. and drill on to 2108ft.

Circulate and POOH.

RIH with Bit # 7, run sequence # 8.

Reaming from 2055ft. to 2108ft. working through bridges at 2065ft. to 2091ft.

Drill ahead from 2108ft. to 2398ft.

Drilling Day # 10 (14.7.82)

Drill from 2398ft. to 2582ft.

Circulate for 10 minutes spot 50 bbls gel mud.

Totco survey at 2582ft. deviation 1 deg.

Drill ahead from 2582ft. to 3185ft. with flow checks at 2679ft. 2855ft, 3004ft, and 3185ft for drilling breaks - no flow.

Drilling Day # 11 (15.7.82)

Drill ahead from 3185ft to 4158ft with flow checks at 3381ft, 3548ft, 3652ft, 3850ft and 4034ft for drilling breaks - no flow.

Drilling Day # 12 (16.7.82)

Circulate, pump 70 bbls of mud, high viscous pill and circulate out.

POOH. Tight hole from 3470ft to 2250ft, 10/20000 lbs overpull.

Pick up monel, RIH with Bit # RP3, run sequence # 9.

Bridge at 2438ft, wash and ream from 2430ft to 2940ft.