

Drilling Day # 29 (2.8.82) cont.

Drill ahead to 6282ft.

Circulate and POOH.

RIH with Bit # 17, run sequence # 19.

PIH to casing shoe, wait on weather.

Drilling Day # 30 (3.8.82)

Wait on weather.

RIH, drill ahead to 6310ft.

Wash out at kelly thread, POOH to casing shoe, change kelly.

Drilling Day # 31 (4.8.82)

RIH and drill ahead from 6310ft to 6883ft.

Drilling Day # 32 (5.8.82)

Drill ahead from 6883ft to 6944ft.

Wiper trip, 10 stands.

Drill ahead from 6944ft to 7273ft.

Wiper trip, 5 stands.

Drilling Day # 33 (6.8.82)

Drill ahead to 7614ft.

Wiper trip, 15 stands.

Drill ahead to 7802ft.

Circulate and drop Totco survey.

POOH, deviation 1/2 deg.

RIH with Bit # 18, run sequence # 20.

Drilling Day # 34 (7.8.82)

Reaming from 58ft to bottom.

Drill ahead to 7893ft.

Circulate and POOH.

RIH with Bit # 19, run sequence # 21.

Drilling Day # 35 (8.8.82)

Drill ahead to 8266ft.

Wiper trip, 22 stands.

Drill ahead to 8298ft.