

Drilling Day # 47 (20.3.82)

Drill ahead to 10195ft.

Circulate and POOH.

RIH with Bit # 26,run sequence # 23.

Drill ahead to 10238ft,block off one jet.

Drilling Day # 48 (21.3.82)

Drill ahead to 10367ft.

Circulate and POOH.

RIH with Bit # 27,run sequence # 29.

Drill ahead.

Drilling Day # 49 (22.3.82)

Continue drilling ahead,block off one jet.

Drill on to 10611ft.

Circulate and POOH.

RIH with Bit # 23,run sequence # 30.

Drilling Day # 50 (23.8.82)

Continue RIH.

Drill ahead,block off one jet.

Drilling Day # 51 (24.3.82)

Continue drilling to 10355ft.

Circulate and POOH.

RIH with Bit # 29,run sequence # 31.

Drill ahead,block off one jet.

Drilling Day # 52 (25.3.82)

Drill ahead to 11050ft.

Circulate and POOH.

Drilling Day # 53 (26.3.82)

Continue POOH.

RIH with Bit # 30,run sequence # 32.

Cut and slip line.

Drill ahead to 11103ft.