

Blue Tier Drill Core Sample Preparation

AR

892208

The following method of preparation is to be used for all Blue Tier Core Samples from 1 June 1980:

Jaw Crush

1200g

Jaws and tray cleaned thoroughly.

Rolls Crush

1200g

Rolls and tray cleaned thoroughly
Empty sample from tray into riffle box, replace tray and re-rolls crush.

Rolls Crush

1200g

Riffle out

$\frac{1}{4}$ of sample

Riffle twice for $\frac{1}{4}:\frac{3}{4}$ split.
For bags with more than 1 m riffle three times.

$\frac{3}{4}$ To Reject Bag
REJECT

00g
Reject Box (shed)

$\frac{1}{4}$ To

Pulveriser (1 minute)

300g

Roll on mat

300g

Spatula out

1 volume measure

Reject to waste

200g

**Pulverise for $1\frac{1}{2}$ minutes
HEAD**

100g

Assay