

S & M Mine Traverse Sheet

Station	Bearing	Red Bearing	CD	Dist	N	S	E	W	N	S	E	W
3 H												
6 3 I	180° 04'	00° 04'	S.W.	115.1		115.1		.13			From Station X	
3/2 A	267° 00'	87° 00'	S.W.	98		5.1		97.86			1150.72	456.71
											1155.82	358.85
3/4 E												
6 3/4 F	88° 12'	88° 12'	N.E.	120.5	3.78			120.09			990.33	752.82
3/4 F	87° 55'	87° 55'	N.E.	92.55	3.3			92.97			987.03	845.29
												old tempy station
												new station
4 0	274° 28'	4° 28'	N.W.	67.7	5.27			67.49			977.226	615.449
4 1/2 A	184° 55'	4.55'	S.W.	128.1		127.6		10.97			1107.826	607.779

5 cm

Wm S. Hutchins
28/7/13