

0374_3199

5 cm

UNIVERSAL WIRE EXTENSOMETER

NUMBERS : 65-69

INSTALLATION DETAILS

PILLAR _____

BEARING _____

R.L. _____

DATE : _____

LOCATION : _____

SENSITIVITY _____ 0.0092 mm/unit change.

DATE	DAY	NO. 65			NO. 66			NO. 67			NO. 68			NO. 69		
		V _{x100}	ΔV _{x100}	mm	V _{x100}	ΔV _{x100}	mm	V _{x100}	ΔV _{x100}	mm	V _{x100}	ΔV _{x100}	mm	V ₁₀₀	ΔV ₁₀₀	mm
1.8.83		114			3			+64			-9			-16		
9.8.83		-3094			-464	-467	-4.29	-458	-522	-4.80	-541	-532	-4.89	-473	-457	-4.20
19.8.83		-300			-471			-460			-517			-480		
30.8.83		-2976			-476			-469			-526			-484		
20.9.83		-2950			-487			-483			-574			-494		
11.10.83		-3025			-460			-456			-522			-463		
27.10.83		-3198			-460	-463	-4.26	-458	-522	-4.80	-528	-521	-4.79	-468	-454	-4.16
8.11.83		-3055			-467			-459			-530			-469		
24.11.83		-3327			-474			-461			-551			-471		
5.12.83		-3035			-473	-476	-4.37	-464	-528	-4.85	-494	-503	-4.62	-473	-457	-4.20
10.4.84		-2745			-3123			-1538	-1602	-14.73	-3123			-1603	-1587	-14.60
22.5.84		-3162			-3162			-2134	-2198	-20.22	-3197			-1803	-1787	-16.44