



WIND SPEED / DIRECTION
OCTOBER 1st - 11th 1985

MANEUVERING BOARD

SCALES
2:1 3:1



← Rig Heading

LOGARITHMIC TIME SPEED AND DISTANCE SCALE

Use single scale throughout

Use all scales with logarithmic time, speed, and distance scale

TO FIND SPEED: Place one point of divider at appropriate point on distance scale and other point at time on logarithmic scale. Read speed on speed scale.

TO FIND DISTANCE: Or find time on point of divider at appropriate point on speed scale. Read distance on distance scale.

