

DEPTH	DIP ANGLE-AZIMUTH-BEARING			TOOL POSITION ANGLE-AZIMUTH	
4550.0	0			2	0.
4570.0	3	41	N 41 E	2	0.
4592.0	3	61	N 61 E	2	0.
4600.0				0	0.
4613.0	5	131	S 49 E	2	0.
4638.0	7	200	S 20 W	3	0.
4642.0	23	181	S 1 W	3	0.
4672.0	11	141	S 39 E	3	0.
4675.0	4	256	S 76 W	3	0.
4696.0	6	246	S 66 W	3	0.
4700.0				0	0.
4715.0	10	84	N 84 E	3	0.5 121
4721.0	7	32	N 32 E	3	0.5 151
4760.0	3	167	S 13 E	3	0.7 135
4774.0	6	41	N 41 E	2	0.5 135
4775.0	5	174	S 6 E	2	0.5 136
4790.5	3	226	S 46 W	2	0.
4800.0				0	0.5 150
4801.0	26	143	S 37 E	3	0.5 141
4818.0	2	168	S 12 E	2	0.5 165
4828.0	3	191	S 11 W	3	0.
4829.5	7	237	S 57 W	2	0.
4830.5	9	150	S 30 E	3	0.
4848.0	0			3	0.
4855.0	10	149	S 31 E	3	0.

DEPTH	DIP ANGLE-AZIMUTH-BEARING			TOOL POSITION ANGLE-AZIMUTH	
4875.0	0			2	0.
4887.0	0			3	0.
4898.0	28	75	N 75 E	3	0.
4900.0				0	0.
4912.0	0			3	0.
4930.0	0			2	0.
4954.0	12	46	N 46 E	3	0.
4966.0	0			3	0.
4979.0	0			3	0.
4985.0	5	274	N 86 W	2	0.
4986.0	4	82	N 82 E	2	0.
4990.0	8	217	S 37 W	2	0.
5000.0				0	0.
5006.0	12	178	S 2 E	3	0.
5013.0	3	91	S 89 E	2	0.
5026.0	0			3	0.
5045.0	7	84	N 84 E	2	0.
5056.0	12	92	S 88 E	3	0.
5070.0	8	335	N 25 W	3	0.
5098.0	5	139	S 41 E	2	0.
5100.0				0	0.
5113.0	8	267	S 87 W	3	0.
5128.0	5	151	S 29 E	2	0.
5145.0	17	124	S 56 E	2	0.
5148.0	37	295	N 65 W	3	0.